

**Wall Assembly** - The HealthWay deodorizer can be easily mounted onto a wall surface providing there is a power supply source close enough to plug in the units 120volt electrical supply adapter. Once the wall surface location is determined, using the template and instructions located in the enclosed plastic bag, drill holes in the wall. The screws and moly's are found in the bag as well for sheet rock mounting. Hang the unit using the slotted fittings (7) on the back underside of the deodorizer.

**HealthWay Deodorizer Specifications:**

**Model Number:** HW-DEO1 **Size:** 11 1/2" x 6 3/4" x 6 1/2" **Weight:** 2 lbs.  
**Color:** Silver **Power Consumption:** 21 Watts **Power Converter:** Supplied with AC 110-120 Volt 60Hz 10W output adapter.

**Limited Warranty**

This HealthWay Deodorizer is warranted to be free of any operating defects for a period of 90-days from date of receipt providing Manufacturer's Warranty Card (enclosed) has been completed for registration and mailed to HealthWay Home Products, Inc. Should any defect occur anytime within the 90-day warranty period, purchaser is requested to contact either their HealthWay distributor or HealthWay Home Products, Inc. directly. Otherwise, purchaser will be advised if the replacement part(s) with instructions are available to purchaser. HealthWay shall not be liable for property, incidental, and/or consequential damages of any kind and, unless otherwise prescribed by applicable state law, HealthWay shall not be liable for personal injury resulting from malfunctions, defects, misuse, improper operation or installation, or alteration of a HealthWay product or any part thereof. The exclusive remedy for a breach of this Limited Warranty is the repair or replacement of the defective product. In no case, shall liability under any other remedy prescribed by law exceed the purchase price of the product. Repairs are made at the cost of component(s) part(s) plus shipping and handling.

---

Thank You! We appreciate your purchase of this uniquely designed multi-purpose ("activated oxygen") producing air-deodorizing appliance. Normal use and care will provide you with years of reliable carefree service. Should you have any questions about your deodorizing unit, feel free to contact your local distributor or call HealthWay directly. Please return enclosed Warranty.

**For More Information, please contact your local HealthWay distributor or call us direct at:**

**HealthWay®**

3420 Maple Avenue, PO Box 485  
Pulaski, New York 13142-0485  
Ph. 1.800.843.3860 FAX: 315.298.6992

# HealthWay's New Air Deodorizer

Clean air has never  
been easier!



## Use and Care Instructions

**HealthWay®**

3420 Maple Avenue, PO Box 485  
Pulaski, New York 13142-0485  
Ph. 1.800.843.3860 FAX: 315.298.6992

**Features:** Your HealthWay Deodorizer is an attractive lightweight portable air-deodorizing unit that can easily be moved from room to room or kept conveniently on any desktop or tabletop. It can also be wall mounted if desired. Whenever the deodorizer unit is in use, it will mitigate odors generated by household chemicals, pets, smoke, mildew, new carpet, ammonia, etc. It can also be utilized to help rid indoor air of many airborne pollutants including mold spores, bacteria and fungi. There is a unique automatic 24-hour timer with 15-minute interval settings. Your deodorizer unit can be run continuously or it can be set to run during time intervals you choose to set to eliminate specific odors.

**Caution:** People have different levels of sensitivity to ozone whether it is naturally occurring or generated. Therefore, using the HealthWay Deodorizer responsibly should be of upmost consideration. Do not operate the deodorizer in confined spaces for long periods of time when that space is being occupied. The deodorizer is best used when space is unoccupied. **Suggested Applications:** - Your deodorizer can be used in the home, apartment, office, etc. to mitigate pet odors, bathroom odors, smoke, mildew, etc. It can also be used in beauty salons, nursing homes, veterinary clinics and virtually anywhere odors are prevalent and need to be eliminated.



**Air Deodorizer Component Parts:**

1. Air intake port
2. Air exhaust port
3. 24-hour timer/dial
4. On/Off light indicator - Red off/Green On
5. Deodorizing/Disinfecting Button
6. 120-volt A/C power supply input plug
7. Wall mounting slotted fittings
8. Access panel to air deodorizer bulb

**WHAT IS A 24 HOUR CLOCK?**

A 24 hour clock is based on military time. 1:00 a.m. thru 12:00 p.m. is 1-12 on the dial. 1:00 p.m. thru 12:00 a.m. is the same as 13 thru 24 on the dial. The 4 small index lines between each number on the dial are 15 minute increments. An example of military time would be: 16:00 hours - this is the same as 4:00 p.m. Setting the clock: Set the arrow on the internal dial to the correct time. As an example: if it is 5:15 p.m. move the arrow to 17 and then to the first small index line between 17 and 18.



**OPERATION—24-HOUR TIMER:** For user convenience, the factory has set all 96 red buttons on the timer to the on position. When the unit is plugged in, the unit will operate 24 hours - continuously. To use the deodorizer in different locations, plug and unplug the unit from a proper electrical source and the unit will come on.

**AUTOMATIC MODE:** Set the timer to the current time of day. To have the unit run from 9:00 a.m. to 4:15 p.m., while you are at work or away, push the red timer buttons out between numbers 9 and 16 and first small index line between 16 and 17. The deodorizer will not operate during the time that any given timer button is not pushed out.

**NOTE:** The timer's internal clock will not operate unless there is an electrical supply source plugged into the unit. The 15-minute time interval button(s) must be pushed to the on position for the deodorizer to operate during the time interval(s) set.

# Deodorizer or Disinfect

Your HealthWay Deodorizer has two settings:

**Deodorizer -**

Pushing the button once, allows for a lower level of activated oxygen to be generated, which will eliminate minor odors.

**Disinfect -**

With the button pushed in twice (as shown in the photo) high levels of deodorizing and disinfecting can be done.

**IMPORTANT:** The operation of the unit at this level (Disinfecting) should only be done in unoccupied spaces.



# Deodorizer Kit Replacement Instructions

**Caution:** The HealthWay Deodorizer must be unplugged from its electrical power source before the old deodorizer kit is to be removed from the system. Failure to unplug the system before removing the old deodorizer kit could result in electrical shock.

Remove the four screws in the panel cover located on the back of the system using a no. 2 Phillips Head screwdriver. (Fig. 1)



Fig. 1

Pull out panel, remove blue lead connector, be careful not to pull on the wires too hard. (Fig. 2)



Fig. 2

Pull all the way out, again be careful not to pull on the wires too hard, and remove the red lead connector. (Fig. 3)

**Reinstalling Deodorizer Kit:** Install deodorizer kit with arrows on panel pointing towards end vent. Re-attach red lead connector making sure the connector is seated properly. Start to carefully push the deodorizer kit back into the system. Now reconnect the blue lead connector making sure it is also seated properly. Push deodorizer kit back into unit and replace the (4) screws to reattach the deodorizer kit panel/cover correctly with arrows pointing towards end vent as pictured. Your HealthWay Deodorizer can now be re-connected to its electrical power source and turned on.



Fig. 3

**Maintenance Requirement:**

- Be sure to dust the bulb in the deodorizer kit approximately every 90 days. Follow instructions above to remove back panel and expose the deodorizer bulb for dusting.
- The deodorizer bulb should be changed once a year for optimum performance.
- It is of the upmost importance to put the panel on correctly with arrows pointing towards the end vent as pictured on panel, as well as on Caution Label.